

Programming Your SmartStat TH115-F-120GA Thermostat

1. Set The Time and Date

Remove the cover from the thermostat and use the buttons on the bottom left. Simply press on **DAY** as many times as needed to get to the right day. Do the same with **HOURL** and **MIN** to set the current time.

2. Program The Time Settings

Unless you want to leave your thermostat on 24/7, you will have to select "heating periods". You can program up to four periods per day.


We'll follow a classic example for a bathroom, where we'll heat from 7 to 10 AM and from 5 to 8 PM.

1. Press on **PGM**, until the screen shows a little house with the number 1 inside (🏠¹). This is the start of the first heating period.
2. To program the same settings for every day of the week, press on **DAY** for three seconds. All the days should appear on the screen.
3. Using **HOURL** and **MIN**, select the start time, 7 AM in our example.
4. Press on **PGM** again, to see the second house with a number 2 inside (🏠²).
5. Using **HOURL** and **MIN**, select the ending time of the first period, here 10 AM.
6. Press on **PGM** to see the third house (🏠³).
7. Again, using **HOURL** and **MIN** select the start of the second heating period, here 5 PM.
8. Press one last time on **PGM** to see the fourth and last house (🏠⁴).
9. Select the ending time of the second period with **HOURL** and **MIN**, here 8 PM.
10. Press on **MODE**

You can also heat from morning to evening (which is common in kitchens) and only use one "period".

3. Set The Day And Night Temperatures

During the programmed periods, the thermostat will pull the temperature requested under the "☀" settings (logo at bottom right of the thermostat). Between the periods, the "☾" settings will be applied.



To select a comfort temperature (☀), use the up and down arrows until you reach the requested temperature and press immediately on ☀ for 3 seconds. After a few seconds, the original (current) floor temperature should be displayed again. To select the "off-peak" temperature, use the arrows and press on ☾ for 3 seconds.

Little flames on the screen should (🔥) show if the product is heating.

4. Recommendation

To change the settings for the weekend or to set the thermostat when you are away for longer periods of time, please refer to the complete instructions included with your control.

An average heating temperature is usually between 80 to 82 degrees. If you chose an "off-peak" temperature that is much lower, the thermostat will take longer to reach the comfort level. If you choose an off-peak temperature, of between 70 to 75 degrees, the thermostat will quickly return to the comfort level. Since every installation is different (subfloor, flooring, insulation, comfort levels) it is up to you to find your favorite settings.

5. Manual And Automatic

The thermostat can be switched from manual to automatic by pressing the **MODE** button. Manual settings will show a "🏠^{MAN}" at the bottom left of the screen while automatic settings will show a "🏠^{AUTO}". Time and temperature settings will only be respected in the automatic (🏠^{AUTO}) mode. In manual, it will keep your floor at the comfort (☀) level.

6. Contact

For more information or in case of problems, call AUBE TECHNOLOGIES at 1-800-831-AUBE or WARMLYYOURS at **800.875.5285**. You can email us at info@warmlyyours.com for feedback and details. ENJOY YOUR WARM FLOORS!