

# TempZone<sup>®</sup> Cable

## Check List

### Materials and Tools Required:

- ☐ WarmlyYours TempZone Heating Cable
- ☐ Thermostat with Sensor Probe Wire (if applicable)
- ☐ Custom Design Layout (provided free with quote)
- ☐ Digital Ohm Meter (required for completion of warranty registration card)
- ☐ Circuit Check (sold separately)
- ☐ Scissors
- ☐ Duct Tape or Box Tape (we recommend 3M 6969 Hi-Temp Duct Tape)
- ☐ Plastic Notched Trowel
- ☐ Self-leveling Cement (for installation with Cable Fixing Strips)
- ☐ ThermalSheet Insulating Underlayment (WarmlyYours offers this product for installing floor heating systems over concrete. This is recommended to increase efficiency, but is not mandatory)
- ☐ Single Gang Electrical Box/es
- ☐ Conduit and Hardware (if required)
- ☐ Licensed Electrician
- ☐ Available Breaker Box Opening/s for Powering the Floor
- ☐ Hot Glue Gun (if using hot glue to secure the Cable Fixing Strips)
- ☐ Industrial-grade Hot Glue (if using hot glue to secure the Cable Fixing Strips)
- ☐ Staples, Nails, Adhesive, or 1/2" Screws (to attach the Cable Fixing Strips to the subfloor)
- ☐ Modified and/or Unmodified Thinset (if installing with the Prodeso Membrane)
- ☐ Roller and Plastic Flat Trowel (if installing with the Prodeso Membrane)

## Learn More

Videos, Step by Steps, and Project Guides

[www.WarmlyYours.com](http://www.WarmlyYours.com)

Installation Support • (800) 875-5285