



WarmlyYours

Be Connected.

Be Warm. Be Radiant.

Prodeso Cable Installation Membrane Installation Tips

- **This sheet is not a substitute for the Installation Manual. Please read the Installation Manual before installing Prodeso.**
- Unroll the membrane the day before installation to flatten it and avoid any potential 'memory' due to environmental conditions.
- Install membrane over entire floor first, then heating cable, THEN do the tiles 1 or 2 at a time. NEVER cover the Prodeso entirely with thin set first. Only apply as much thin set as needed to lay a couple of tiles at a time.
- When laying rolls adjacent to each other, align the square relief pegs for the later heating element cable runs.
- Prodeso does not eliminate the need for expansion joints (adhere to local codes).
- Waterproofing is recommended under and around tubs/showers. It's also recommended wherever the tile could possibly be exposed to considerable amounts of water. Prodeso is naturally waterproof, but the corners and seams need to be treated with waterproofing tape and thin set. (Use Pro WP Waterproofing Band 5" - Soft polyethylene tape – to seal seams.)
- NOT a good choice for mosaic tile work, Prodeso requires 2" x 2" or larger tiles.
- The sensor should be placed at least 6" into an open cable loop, so that it is right in the middle of two straight runs. This way the sensor won't sense the set temp until the tile is evenly heated.
- Self-Leveling (SLC) Cement is not recommended for use over Prodeso. Contact WarmlyYours if self-leveling underlayment is required.