



WarmlyYours

TempZone[®] Custom Check List

Materials and Tools Required:

- WarmlyYours TempZone Heating Mats

- Thermostat with Sensor Probe Wire (if applicable)

- Custom Design Layout (provided free with quote)

- Digital Ohm Meter (required for completion of warranty registration card)

- Circuit Check (sold separately)

- Scissors

- Duct Tape or Box Tape (we recommend 3M 6969 Hi-Temp Duct Tape)

- Plastic Notched Trowel

- Self-leveling Cement (for installation with Cable Fixing Strips)

- ¼" Cork or 3/16" CeraZorb[®] Concrete Insulating Underlayment (WarmlyYours offers both of these products, which are recommended when installing over concrete. This is recommended to increase efficiency, but is not mandatory)

- Single Gang Electrical Box/es

- Conduit and Hardware (if required)

- Licensed Electrician

- Available Breaker Box Opening/s for Powering the Floor

- Hot Glue Gun (concrete applications)

Learn More

Videos, Step by Steps, and Project Guides

www.WarmlyYours.com

Installation Support • (800) 875-5285