








WarmlyYours floor heating systems are offered with a variety of Control Options to meet your needs and personal comfort requirements. All controls come with easy-to-follow installation and operating instructions. For more detailed information, contact a WarmlyYours Service Representative at (800) 875-5285.

	<p>SmartStat™ Programmable Thermostat CSA Listed</p> <p>This premium, multi-function thermostat provides homeowners total control over their floor heating system with full 7-day, 4 events per day programming capabilities for maximum comfort and system enjoyment.¹</p> <ul style="list-style-type: none"> • 7-day, 4 events per day programming • Early Start Function raises the floors temperature to the desired heat setting by the time specified • Floor Sensor provides precise temperature control • Ground Fault Circuit Interrupter (GFCI) • On/Standby switch <p style="text-align: right;">Code # TH115-B-120GA/HW240B (15 Amp capacity)² - \$169.00</p>
	<p>EnergyStat™ Programmable Thermostat CSA Listed</p> <p>This top of the line thermostat provides homeowners with the ability to control their floor warming system with 4 events per day programming, temperature limits and energy usage monitoring for total warming comfort and accurate operating costs.</p> <ul style="list-style-type: none"> • Records power consumption for accurate energy costs • Adaptive function raises floor temperature to required level by the specified time • Ground Fault Circuit Interrupter (GFCI) built in <p style="text-align: right;">Code # OJ-Dual (16 Amp capacity)² - \$169.00</p>
	<p>Comfort Regulator CSA Listed</p> <p>Our Comfort Regulator features a convenient dial to control your preferred comfort level with ease.</p> <ul style="list-style-type: none"> • Easy to operate temperature control dial • Manual on/standby switch • Ground Fault Circuit Interrupter (GFCI) • Silent, worry-free operation <p style="text-align: right;">Code # HWR1GA-15-120 (15 Amp capacity)² - \$85.00</p>
	<p>Relay Contactor UL Listed Components</p> <p>A Relay Contactor is required, in addition to a control, for all floor heating system installations utilizing more than 240 square feet of heating product.</p> <ul style="list-style-type: none"> • Installation friendly terminal blocks • Can be used with both 120 volt and 240 volt systems • Silent operation <p style="text-align: right;">Code # RC-40AMP (Dual Pole , 40 Amp capacity)² - \$295.00</p>
	<p>24V Transformer UL Listed</p> <p>Transformers are required, in addition to a control, when the heating system is used in shower and steam shower applications (24V TempZone™ system).</p> <ul style="list-style-type: none"> • Only required for shower applications • Installation friendly terminal blocks • Overload protection included <p style="text-align: right;"> Code # TR-300VA-Q (20 sq. ft. capacity) - \$239.00 Code # TR-500VA-Q (33 sq. ft. capacity) - \$269.00 Code # TR-750VA-Q (50 sq. ft. capacity) - \$349.00 </p>

¹ We recommend that a SmartStat™ thermostat be used with all hardwood and floating wood floor heating applications where a floor covering manufacturer has specified a maximum heating level for their products.

² To determine how many sq. ft. one control can handle, multiply the Amps by the Volts and divide by Watts per sq. ft. (15 Watts for TempZone;™ 10 Watts for Environ II™).

This Document is the property of WarmlyYours. Subject to change without notice.