




WARMLYYOURS
RADIANT HEATING


WIRING DIAGRAM

FOR 120V & 240V ENVIRON II WITH
THE SMARTSTAT™ / EASYSTAT™ USING A JUNCTION BOX
ITEM #: TH115-AF-GA ITEM #: TH114-AF-GA

FROM POWER SOURCE 120V & 240V




1. ENSURE THE SYSTEM IS GROUNDED
2. MAT HAS NO POLARITY
3. WIRE FROM THERMOSTAT TO JUNCTION BOX SHOULD BE SIZED ACCORDING TO LOCAL ELECTRICAL CODE REQUIREMENTS.




SENSOR PROBE
THERMOSTAT
SENSOR WIRE
(LOW VOLTAGE)

ELECTRICAL ROUGH-IN


MOUNTING HARDWARE



JUNCTION BOX
WITH COVER



4" x 4" DEEP TWO GANG
SQUARE BOX SUPPLIED
BY CONTRACTOR



SINGLE GANG MUD RING
(PLASTER RING) SUPPLIED
BY CONTRACTOR

