WARMLYYOURS
RADIANT HEATING

Smart PreSet Thermostat Programming Service

Specify Your Smart PreSet In-Warehouse Programming Details

Energy efficiency is just a program away! WarmlyYours will program your SmartStat™ programmable thermostat, in the WarmlyYours warehouse prior to shipment – preset to your lifestyle, daily schedule, ambient and floor temperature settings.

Benefits of the Smart PreSet Thermostat Programming Service

- Intelligent programming to ensure accurate, consistent, floor temperature
- Increased energy efficiency and savings
- Full functionality of your thermostat and radiant heating system
- Quick response to requests and customization to fit your needs

Important Information on Settings

- **Time:** The time of the SmartStat™ thermostat will need to be programmed by the customer when powered up.
- **Default Settings:** WarmlyYours SmartStat™ programmable thermostats are set with *two weekday warming periods*, Monday–Friday: 6:00 a.m.–8:30 a.m. & 5:00 p.m.–11:00 p.m., and *one weekend warming period*, Saturday–Sunday: 6:00 a.m.–11:00 p.m.
- **F Mode:** Controls the floor temperature using an external temperature sensor, located in the floor. This mode is **STRONGLY** recommended by WarmlyYours, for optimum heating and temperature control.
- **A Mode:** Controls the ambient air temperature.
- **AF Mode:** Controls the ambient air temperature and maintains the floor temperature within desired limits.
- **Floor Temperature Limits (AF Mode Only):** When setting the temperature, ensure compliance with the floor covering manufacturer's required maximum temperature limit, as it applies to your floor covering type. For AF Mode, the default temperature limits are 41°F min. and 82°F max.

Name	
Address	
Email	
Phone Number	

Order Number	
For SmartStat #	

STEP 1
Basic Thermostat Settings Selection

- Some thermostat configurations can be modified via manual switches on the back of the faceplate (control module).
- Please note, as a guide/example, that the default (factory) settings are noted in the gray boxes.
- Early Start mode is **STRONGLY** recommended.

Main Settings	Configurations	Default Settings	Check for Default Setting	Optional Settings	Check for Optional Setting
1	Display Format	Farenheit / 12H		Celsius / 24H	
2	Early Start	Enable		Disable	
3	Temperature control mode	F		A/AF	

WARMLYYOURS
RADIANT HEATING

STEP 2
Temperature Setting Selection

- Please select your Temperature Settings preference, below.
- Floor Temperature Mode is **STRONGLY** recommended over Ambient or Ambient/Floor modes.
- Please note, as a guide/example, that the default settings are noted in the gray boxes.
- **AF MODE ONLY (Floor Temperature Limits):** When setting the temperature, ensure compliance with the floor covering manufacturer's required maximum temperature limit, if it applies to your floor covering type. For AF Mode, the default temperature limits on the thermostat are 41°F/5.0°C (minimum) and 82°F/28°C (maximum).
  - Please indicate the flooring manufacturer's minimum temperature limit _____
  - Please indicate the flooring manufacturer's maximum temperature limit _____

Icon	Intended Use	Floor Temperature	Add Preferred Temperature	Ambient Temperature	Add Preferred Temperature	Ambient-Floor Temperature	Add Preferred Temperature
☼	Comfort	82°F (28°C)		70 °F (21 °C)		70 °F (21 °C)	
☾	Economy	68°F (20°C)		63 °F (17 °C)		63 °F (17 °C)	
💼	Vacation	50°F (10°C)		50°F (10°C)		50°F (10°C)	

STEP 3
Warming Schedule Selection

- Please select your Temperature/Warming Schedule preference, below.
- Please note, as a guide/example, that the default (factory) settings are noted in the gray boxes.
- If **Early Start** mode is enabled, indicate the time by which you want your floor fully heated, if disabled, please indicate your warming time to be 30-45 minutes earlier to allow for floor warm-up time.

Period	Setting	MONDAY (Default)	Customize Your Warming Time	TUESDAY (Default)	Customize Your Warming Time	Wednesday (Default)	Customize Your Warming Time
1	☼ (morning)	6:00a		6:00a		6:00a	
2	☾ (work)	8:30a		8:30a		8:30a	
3	☼ (evening)	5:00p		5:00p		5:00p	
4	☾ (bedtime)	11:00p		11:00p		11:00p	

Period	Setting	THURSDAY (Default)	Customize Your Warming Time	FRIDAY (Default)	Customize Your Warming Time
1	☼ (morning)	6:00a		6:00a	
2	☾ (work)	8:30a		8:30a	
3	☼ (evening)	5:00p		5:00p	
4	☾ (bedtime)	11:00p		11:00p	

Period	Setting	SATURDAY (Default)	Customize Your Warming Time	SUNDAY (Default)	Customize Your Warming Time
1	☼ (morning)	6:00a		6:00a	
2	☾ (work)	--		--	
3	☼ (evening)	--		--	
4	☾ (bedtime)	11:00p		11:00p	